Sensational Action Toy

CAPTAIN MARVEL JR. IN

SKI JUMP

NO CUTTING • NO PASTING
EASY TO ASSEMBLE

Complete
IN THIS ENVELOPE

10¢

Produced by REED & ASSOCIATES, INC., CHICAGO, Patent Pending

© Fawcett Publications, Inc.

He soars through the air. He makes a perfect landing on his skis!

M
G
L
J
M
G
F
D
M
G
Produced by
REED AND ASSOCIATES, INC., CHICAGO
PAT. PENDING
© FAWCETT PUBLICATIONS, INC.
THE DIME LINE
F
E
D
C
Z
O
A
Y
J
H
A
Y
L
K

INSTRUCTIONS FOR ASSEMBLY

Unfold your sheet. Carefully press out the separate parts from the sheet and lay them in front of you, printed side up.

STEP ONE Pick up your SKI FRAME (See Fig. 1). Bend down on all scores. Now lay it *Printed Side Down* in front of you. Pick up SKI WEIGHT (Fig. 1) and insert it through front openings on SKI FRAME—so that small side tabs on SKI WEIGHT can be locked into small side slots on SKI FRAME. The Crossbar on SKI WEIGHT will now rest snugly against front of SKI FRAME. Bend down ends G and M on SKI FRAME.

STEP TWO Pick up figure of CAPTAIN MARVEL, JR. *Bend Up* boot tab JL and boot tab FD. *Bend Down* on all other scores. Close lower part of legs by wrapping long tabs A around top of boots and inserting ends into slots A on inner sides of legs. Bend tabs H and K down and underneath boot tabs J and L. Insert folded tab JH into slot J on SKI FRAME and folded tab LK into slot L. Unfold tabs H and K so that leg will be locked to SKI FRAME. Attach the other leg the same manner.

STEP THREE Now bend down Side 1 of SKI FRAME (See Fig. 1). Push tab G into slot G and tab M into slot M. Bend down side 2 and push A on side 2 under B on side 1 (Fig. 1). Push C-C on Side 1 under D-D on Side 2. Lock Side 2 in place by pushing tab G into slot G and tab M into slot M. Close figure of CAPTAIN MARVEL, JR. by pushing tab N into slot N and tab O into slot O (See Fig. 2).

STEP FOUR Bend SKI POLES down along center score and push them into slots of CAPTAIN MARVEL JR'S hands. Push CIRCULAR ENDS on poles as shown in Fig. 2. Bend small end tabs on SKI POLES outward to lock in place.

CAPTAIN MARVEL, JR., is now ready to make a tremendous leap. Grasp the SKI FRAME between the thumb and forefingers and launch him smoothly through the air. He will soar skillfully and make a perfect upright landing on his skis.



FIG. 1



FIG. 2

RILLY AND PAINT IN "COMIC CAPERS"

Watch them Gesture—Point—Act as they Read the Adventures of Captain Marvel

OSCAR AND FRIDAY IN "COMIC CLOCK"

Clock Dials actually Move—They "Spell" the Time—Famous Fawcett Characters Appear—Friday Names Them—Triple Action—Triple Thrills

HOPPY AND MILLIE IN "MUSICAL EVENING"

Millie sings with Gestures while Hoppy plays the Bass Fiddle with Gusto—Chuckles and Chortles for One and All



MODEL FLAT-TOP

Big—Beautiful—Authentic in Every Detail—A Pleasure to Build and Own

NEWEST SUPER-DREADNAUGHT

Revolving Gun Turrets—Impressive in Size. Complete in all Details—Just like the Real Thing!

1/16 OF AN INCH THICK

CAPTAIN MARVEL JR. IN SKI JUMP

CARDBOARD PIECE

FROM THE LONG BOX OF

The UNKNOWN SCANNER





Sensational Action Toy

CAPTAIN MARVEL JR. IN

SKI JUMP

Reed & Associates, 1944, Env. & 2 pieces.

© Fawcett Publications, Inc

ImageShacked 17-OCT-2005